


Foldable Magnifying Glass

Instruction Manual

Art. No.:1100047




Main details


- Magnification: 2x
- Lights: 5 LED, 2 levels
- Focus Length: 250mm
- Battery: 3 "AAA" (Not included)
- Lens size: 108x63mm

Operation:


- Change light modus: Press the LED switch once to turn on the LED "soft light", press again to switch to "strong light", press the switch for a third time to turn off the lighting.
- Battery replacement: Press the battery cover with your finger and slide back to open the battery compartment. Remove the old battery and load three new 1.5V AAA batteries according to the positive and negative marks at the bottom of the compartment. Then push the battery compartment cover back and close.



Open battery compartment



Insert 3 "AAA" 1.5V batteries



Close the battery compartment

NOTES:

- Do not place the magnifying glass in the direct sunlight, to not cause fire.
- Do not use the magnifying glass to observe the sun, to not burn your eyes.
- Please clean the lens with a soft cloth or a mirror paper.
- Lenses can also be cleaned with a small amount of detergent and wet cloth, and then wipe with clean wet cloth.
- Do not use alcohol, gasoline and other chemical liquids to wipe lens and shell.

DISPOSAL:

The packaging material is reusable. Dispose of the packaging in an environmentally friendly way by putting it in the appropriate recyclable waste collection containers.



Dispose of the product and the batteries in view of the environment if you want to separate. The device and the batteries must not be thrown in with domestic waste. Take them to a recycling center for used electrical and electronic devices. For more information you can consult your local government. Remove batteries first.

Eurotops Versand GmbH
Elisabeth-Selbert-Straße 3
40764 Langenfeld, Germany



If technical support is needed, please call ...

in Germany	0180 . 530 63 63* or info@eurotops.de
in Austria	0720 204 001 or info@eurotops.at
in Switzerland	071/ 27 4 68 06 or info@eurotops.ch
in the Netherlands	026 . 37 36 333 or info@eurotops.nl
in France	0892 . 700 470** or info@eurotops.fr
in Belgium	070 663 665*** or info@eurotops.be

* 14 Cents/minute via German landline, max. 42 cents/minute via mobile phone network

**34 Cents/minute via French landline

*** 30 Cents/minute via Belgium landline

A possible return of products should be addressed to the return address stated on your invoice.

© 23.09.2019