

Instructions

Product number: Z 08550

Dear customer,

We are delighted that you have decided on this **LED flower tree**. If you have any questions about the product, please contact customer service via our website:

www.service-shopping.de

General notes

- This product is designed for decorating indoor areas. It is not a toy!
- The product is designed for private use, not for commercial use. Only use the product as described in these instructions. Any other use is deemed improper.



Safety instructions

- ATTENTION:** Danger of suffocation exists! Keep the packaging material away from children and animals.
- Only connect the product to a properly installed socket with protective ground contacts. The socket must also be easily accessible after the product has been connected. The mains voltage must comply with the product's technical data. Only use proper extension cords whose technical data correspond to those of the product.
- Ensure that the connected mains cord does not pose a tripping hazard. Do not allow the cord to hang over the edge of a table or kitchen worktop. Someone could catch him/herself and pull down the product.
- Lay the cable such that it is not crushed or creased and such that it does not come into contact with hot surfaces.
- Check the product for damages prior to each use. If the product, the cord or the plug exhibit visible damages, the product may not be used.
- If the product is defective, do not attempt to repair it yourself. In the event of damage, contact the customer service department.
- Remove the power plug from the socket
 - if you are not using the product,
 - before a storm,
 - before you clean it.
- If you wish to remove the mains plug from the socket, never pull on the cable, but always on the plug.
- Never touch the product, the cable or the plug with wet hands.
- Do not subject the product to extreme temperatures, severe changes in temperatures, direct sunlight or moisture.
- Maintain adequate distance to heat sources such as stovetops, ovens, fireplaces or burning candles.
- Do not allow the product to fall and do not subject it to strong percussions.
- Only use the product in enclosed areas. Not suitable for wet rooms such as bathrooms.
- Ensure that the product does not fall in water or is at risk of getting wet. When needed, dust off the product with a soft, dry cloth. Heavily laden dirt can be wiped off with a damp cloth.
- If the product is defective, do not attempt to repair it yourself. In the event of damage, contact the customer service department.

Warranty conditions

Defects arising due to improper handling, damage or attempts at repair are excluded from the warranty. This also applies to normal wear and tear.

Product contents

- 1 LED flower tree with mains adapter and flower heads

Before first use

1. Unpack all parts. Check that the product contents are complete and that they do not exhibit any transport damages. Should you identify any transport damage, do not use the product(!); instead please promptly consult the customer service department.
2. Hold onto the packaging to store the product when not in use.
3. The flower tree twigs and branches can be bent. Be careful when bending them.
4. Mount the enclosed flower heads on the LEDs.
5. Connect the flower tree's jack plug to the mains adapter.

Use

1. Place the flower tree on a level, stable surface.
2. Connect the mains adapter to a properly installed socket in order to turn on the LEDs.
3. Pull the mains adapter out of the socket to turn off the LEDs.

Cleaning and storage

- When needed, clean the product with a dust cloth.
- Store the product in the original packaging if you do not use it for a prolonged period of time.
- Store the product in a dry area that is out of the reach of children and animals and that is not exposed to direct sunlight.

Technical data

Input voltage:	230 – 240V ~ / 50 Hz
Output voltage:	24V ~ / 150 mA / 3.6 VA
Protection class:	IP20
Model number:	
Flower tree:	YF8056A-IP20-2-48
Adapter:	MAI-2400100



Disposal



Dispose of the packaging material in an environmental-friendly manner. It can be recycled. Make it available to the collection service for recyclable materials.



Dispose of the product in an environmentally-friendly manner. It does not belong in the household garbage. Dispose of it at a recycling centre for old electrical and electronic equipment. For more information, please contact the administration in your community.