

# English

- Push the plunger (1).
  - Notice: To avoid risk of burning, do not touch the igniting coil
  - Use the USB charger wire for charging battery (2)
  - The cigarette can be inflamed when the igniting device turn into red
- For the safety of consumer, the heating wire will auto stop beyond 12 seconds per ignition.

## How to charge

It is recommended a complete recharge before product first use.


- Use the USB charger wire for charging battery (2)
- Connect the Mini USB port to the USB port of the computer, or any USB port with exit DC5V+/ -0.5V, 300mA
- Complete recharge in approximately 3 hours until the light goes out (3)

If it remains with low battery by a period and the cigarette is difficult to be ignited, please recharge the batteries. Do not push cigarette end hard onto coil for ignition, the igniter would become unusable and not work anymore. After battery recharge, please take off the lighter from charger.

This rechargeable lighter has an inserted circuit of protection. In case the ignition device remains overheated, the circuit of protection will cut automatically the supply of the battery. In order to release the circuit of protection, it will be necessary to link/connect the rechargeable lighter to the USB entry.

## Attention:

- Keep away from children
- Do not put or leave this product in any kind of liquid.
- If overheating occurs, suspend the use and leave it cooling down before using it again.
- Do not touch the igniting coil because it can cause burn and injuries
- The unaided use of this lighter by disabled people could be dangerous
- To clean the surface, use a dry and smooth cloth
- Do not insert objects in the opening parts of the device; do not expose to the fire; do not connect to any unsuitable power, do not try to disassemble this product; take care of any crash/collision.
- To use this product follow the indications from this instruction manual.



(1) Push the plunger  
N'utilisez pas le bouton noir central, ne le touchez pas.

(2) Use the USB charger wire for charging battery  
Utilisez le câble USB pour charger la batterie.

(3) Battery is charged when RED light turns to green  
La batterie est chargée quand la lumière rouge devient verte.

# French

- Libérer la sécurité en appuyant sur le bouton noir central situé sur le poussoir (1) et actionner le poussoir vers le bas pour ouvrir le brûleur (2)
- Attention : afin de ne pas se brûler, ne pas toucher la résistance
- La cigarette peut être allumée lorsque le brûleur devient rouge

## Comment recharger :

Il est recommandé de charger complètement le briquet avant la première utilisation.

Baisser le bouton sur le côté afin de sortir la clé USB (3)

Insérer la clé USB dans le port USB de l'ordinateur, ou tout autre port USB avec sorties DC5V+/ -0.5V, 300mA.

Le rechargement total dure approximativement 3 heures jusqu'à ce que la lumière devienne verte (4)

Si le briquet reste pendant une période faiblement chargé et qu'il est difficile d'allumer la cigarette, il faut recharger les piles. Ne pas presser la cigarette à fond sur le brûleur pour réallumer, car il deviendrait inutilisable et ne fonctionnerait plus. Une fois la pile rechargée, appuyer le briquet du chargeur.

Ce briquet rechargeable a un circuit intégré de protection. Si l'appareil surchauffe, le circuit de protection coupe automatiquement l'approvisionnement de la pile. Afin de rétablir le circuit, il faudra connecter le briquet rechargeable à une entrée USB.

## Attention :

- Tenir éloigné des enfants
- Ne pas mettre ce produit dans un liquide
- S'il y a une surchauffe, attendre que l'appareil refroidisse avant de s'en servir
- Ne pas toucher la résistance car elle peut brûler
- L'utilisation sans assistance de ce produit peut être dangereuse pour les personnes
- Utiliser un chiffon sec et doux pour nettoyer la surface
- Ne pas insérer d'objets dans les parties ouvertes, ne pas exposer au feu, ne pas connecter à un port inapproprié, ne pas démonter ce produit, faire attention à ne pas l'écraser.
- Utiliser ce produit en suivant les instructions de la notice d'utilisation.