


Digital Pest Repeller - Cat. No.: 27437

Instruction



1. Plug the device into the mains. The red light will be on when the device is working.
2. The yellow light indicates the electromagnetic function and the green light the ultrasound function. Both lights blink when the device is working properly.
3. The night light can be turned on by pressing the white button on top of the device. Turn off the night light by pressing the same button.
4. Leave the device on all the day.
5. If you need a second device, make sure it is plugged in far enough away from your other repeller. One repeller unit covers an area of approximately 200m²

Technical specifications

Frequency: 50/60Hz

Power: 230V AC

Current consumption: 0.08A

Warning

1. Do not use this repeller if you have pet rabbits or rodents, as the device may cause them discomfort.
2. The device does not affect other household pets and household appliances.
3. Keep the device away from water, and keep out of reaching children.
4. For indoors use only.
5. When first using this device, it is normal for pests becoming more active and come out of hiding. Best results with cockroaches, spiders, ants, and rodents are achieved after 1 to 3 weeks.
6. When using this device to drive bugs away, remember to leave a window or door open to let them escape
7. Do not use poisons or other chemical products while using the device. These chemicals tend to attract pests while this repeller drives them away.

8. Do not place behind and furniture.

DISPOSAL:

The packaging material is reusable. Dispose of the packaging in an environmentally friendly way by putting it in the appropriate recyclable waste collection containers.



Dispose of the product and the batteries in view of the environment if you want to separate. The device and the batteries must not be thrown in with domestic waste. Take them to a recycling center for used electrical and electronic devices. For more information you can consult your local government. Remove batteries first.

Eurotops Versand GmbH
Elisabeth-Selbert-Straße 3
40764 Langenfeld, Germany



If technical support is needed, please call ...

in Germany 0180 . 530 63 63* or info@eurotops.de

in Austria 01 . 230 60 43 12 or info@eurotops.at

in Switzerland 044 . 28 36 125 or info@eurotops.ch

in the Netherlands 026 . 37 36 333 or info@eurotops.nl

in France 0892 . 700 470** or info@eurotops.fr

* 14 Cents/minute via German landline, max. 42 cents/minute via mobile phone network

**34 Cents/minute via French landline

A possible return of products should be addressed to the return address stated on your invoice.

The manual only reflects the technical conditions available under printing. Any changes in technology and equipment are reserved.

© 09.11.2015