


OPERATING INSTRUCTIONS quartz analog watches with battery Company The Unemployed Philosophers Guild

Please set your watch - in compliance with the diagram - as follows:



Pull the crown out to position B.

Now set hour and minute hands to the correct time. Push the crown back on when the official announcement time (for example on television, radio, telephone) indicating the full minute (= 00Sek.).

Cleaning

Wipe dirt and water drops of the housing, clean watch glass and bracelet with a cloth.

The high functionality of your watch is guaranteed within the temperature range of 10 ° to + 60 ° C.

Battery replacement

Choose to replace the battery always expertly! Battery There is no warranty.

Battery notes

Keep batteries out of the reach of children.

Do not let batteries lay around openly as there is the danger of being swallowed by children or pets.

If swallowed battery, consult a physician immediately.

Leaking or damaged batteries might cause acid burns when touched, therefore, use suitable protective gloves. Batteries may not be shorted, be disassembled or thrown into the fire. Risk of explosion!

Conventional non-rechargeable batteries should not be recharged, explosion risk!

When inserting the battery to the correct polarity (plus / + and minus / -)